

Part# 810 ProFinisher™ Vacuum-Assist Conversion Kit
For ProFinisher™ Models 500, 600 & 700 Sanders

Includes:

- | | |
|------------|--|
| 1-762 | 6" Hookit Vacuum Pad |
| 1-1352-PVN | Vacuum Tube Swivel Complete
(Includes tube and 2 metal attachment screws) |
| 1-1546 | Vacuum Shroud |

Installation Instructions:

- 1) Disconnect the sander from any compressed air supply
- 2) Using # 800 pad wrench, remove pad
- 3) Remove protective shroud part# 1545
- 4) Remove the protective plug located in the motor housing below the muffler
- 5) Install the new vacuum shroud part#1546 supplied in the #810 kit
- 6) When installing the shroud, make sure to align notch in shroud with rib, located in the rear of the housing. Make sure it is securely in place.
- 7) Install the new vacuum pad(part# 762) supplied in the #810 kit
- 8) Put the small end of the supplied vacuum tube into the hole located under the muffler (previously plugged) and secure with the two supplied metal screws
- 9) Attach your vacuum source hose to the swivel end of the vacuum tube then turn on the vacuum source
- 10) Reconnect the air supply and test the tool for vacuum performance

Optional Accessories

- | | |
|--------|--|
| 5301-2 | <u>Quick Change Connector</u> - attaches to Vacuum Tube Swivel (1352-PVN)
In order to connect to standard 1 ½" OD vacuum hose |
| 5301-5 | <u>ProFinisher™ Swivel Connector</u> - attaches to Vacuum Tube Swivel
(1352-PVN) in order to connect 1" OD vacuum hose |